

waterpik® waterflosser®


QUICK START GUIDE

WP-400 Series

1 Unit Prep (First time use only)

Charge Unit for 24 Hours Prior to First Use.

Turn power switch OFF (O), plug power cord into outlet, and insert the charging cord into the unit.






Unplug charging cord from unit prior to filling with water and during use. Lift the flip top on reservoir and fill with lukewarm water. Refill as needed.

Select the appropriate tip and insert into the unit. Press firmly until the tip clicks into place. **To remove tip, push the tip eject button.**

CAUTION:

Do not press tip eject button while unit is running.




waterpik® waterflosser®

QUICK START GUIDE

WP-400 Series

2 Pressure Setting

For first time use, adjust the pressure setting to the **LOW (I)** setting.




Keep unit upright during use to ensure continuous water flow.

3 Water Floss



Lean over sink and close lips enough to prevent splashing, while still allowing water to flow from mouth into the sink. Turn unit ON (I). To increase water pressure move to HI (II) setting.

4 Technique



Aim water at a 90° angle to your gumline. Follow the gumline and pause briefly between teeth.

TO AVOID MESS: KEEP TIP IN MOUTH WHILE UNIT IS ON.